



## Instructions on Setting Up the Condor and Condor XL Annex Room

1. Unfold the Annex shell and find the main zipper.
2. Zip the Annex shell onto the entrance of your Condor or Condor XL.
3. Attach the velcro strips on both sides of your Condor or Condor XL entrance.
4. Take the poles out of the bag and adjust their height to be the same as the floor of your Condor or Condor XL.
5. Take the first guy rope insert one end into the loop on the top left outer corner of the Annex Room and tie a strong knot.
6. Insert the first pole into the left outer corner of the Annex Room and erect it.
7. Stake down the rope and use rope adjuster to tighten it.
8. Repeat this process with the second pole on the right outer corner of the Annex Room.
9. Enter the Annex Room and attach the top of the divider (between the ladder and your vehicle) to the bottom of your Condor or Condor XL 's floor.
11. Exit the Annex Room and proceed to the front (furthest away from your vehicle).
12. Stake the bottom corner on the left making sure it is aligned with the left corner pole and the left corner of your Rπ entrance (the 3 points should form a line).
13. Repeat this process with the stake on the right outside corner.
14. Proceed to stake down one side of the Annex Room then the other, making sure both sides are tight.
15. If needed, adjust the height of the support poles.